


SAVE VTR 200/B



GB User Manual

**The English language is used for the original instructions.
Other languages are a translation of the original instructions.**

(Directive 2006/42/EC)

© 2012 Copyright Systemair AB

Systemair AB can accept no responsibility for possible errors in catalogues, brochures and other printed material. Systemair AB reserves the right to alter its products without notice. This also applies to products already on order provided that such alterations can be made without sub sequential changes being necessary in specifications already agreed.

All trademarks in this material are property of Systemair AB.

All rights reserved.

Contents

| | |
|---|----|
| 1 Warnings..... | 1 |
| 2 Introduction | 1 |
| 3 Control panel..... | 1 |
| 3.1 Display symbols | 2 |
| 4 Configuration..... | 3 |
| 4.1 Start up wizard | 3 |
| 4.1.1 Procedure | 3 |
| 4.1.2 Perform Factory reset..... | 4 |
| 4.2 Temperature settings | 4 |
| 4.3 Manual setting of fan speed | 5 |
| 4.4 Programming the Week schedule | 5 |
| 4.5 Manual and automatic summer mode | 6 |
| 5 Maintenance of the unit | 6 |
| 5.1 Warnings | 6 |
| 5.2 Open the front hatch | 7 |
| 5.3 Changing filters | 7 |
| 5.4 Resetting the filter time | 8 |
| 5.5 Checking and cleaning the heat exchanger | 8 |
| 5.6 Cleaning the fans | 9 |
| 6 Duct system maintenance | 10 |
| 6.1 Cleaning extract louvres and supply air diffusers | 10 |
| 6.2 Checking the outdoor air intake | 10 |
| 6.3 Checking the roof cowl (if fitted)..... | 11 |
| 6.4 Checking and cleaning the duct system | 11 |
| 7 Trouble shooting | 11 |
| 7.1 Alarm list..... | 12 |

1 Warnings

The following admonitions will be presented in different sections of the document:

Danger

- Make sure that the mains supply to the unit is disconnected before performing any maintenance or electrical work!
- All electrical connections and maintenance work must be carried out by an authorized installer and in accordance with local rules and regulations.

Warning

- The system should operate continuously, and only be stopped for maintenance/service.
- The installation of the unit and complete ventilation system must be performed by an authorized installer and in accordance with local rules and regulations.
- Beware of sharp edges during mounting and maintenance. Use protective gloves.
- All though the Mains supply to the unit has been disconnected there is still risk for injury due to rotating parts that have not come to a complete standstill.
- Make sure that filters are mounted before starting the unit.
- This product must only be operated by a person which has suitable knowledge or education within this field or carried out with the supervision of a suitably qualified person.

Caution

- Do not connect tumble dryers to the ventilation system.
- Duct connections/duct ends must be covered during storage and installation.

2 Introduction

The SAVE VTR200 is a heat recovery ventilation unit with a built in rotating highly efficient heat exchanger. The SAVE VTR 200/B is suitable for smaller flats or houses. It supplies filtered outdoor air to residential areas and extract air from bathroom, kitchen and wet rooms.

There are two model options, right (R) and left (L) model. Both models come with 1000W or 500W installed re-heater battery. The different models are recognized by the placing of the internal components. This manual describes basic information how to operate and perform maintenance on a left (L) unit and the system it is connected to.

Note:

This document describes a left (L) model. The inside of a right (R) model is mirrored.

3 Control panel

Below illustration shows the control panel with a short description












Fig. 1 Control panel with display

| Position | Description | Explanation |
|----------|----------------|--|
| 1 | Display | Shows symbols, menus and settings |
| 2 | Selection knob | Move through the menu lists or change settings and values by turning the knob left or right |
| 3 | Confirm button | Confirm menu choices or settings by pressing the button |
| 4 | Back button | Step back in the menu levels and to abort an initiated parameter change and restore the original value by pressing the button. |

3.1 Display symbols

| Symbol | Description | Explanation |
|---|-------------|---|
|  | Temp | <p>Illustrates the current set temperature. The temperature setpoint is done in 6 steps (from completely empty to filled symbol) and can be changed manually by turning the “selection knob”.</p> <p>Confirm the setting with the “confirm button”</p> |
|  | Fan speed | <p>Illustrates the current fan speed. The fan speed can be set manually in 4 steps: (Off, Low, Nom and High) by turning the selection knob and confirming with the confirm button after completed setting.</p> <div style="display: flex; justify-content: space-around; align-items: flex-start;"> <div style="text-align: center;">  A </div> <div style="text-align: center;">  B </div> <div style="text-align: center;">  C </div> <div style="text-align: center;">  D </div> </div> <p>A. Ventilation off¹</p> <p>B. Low ventilation: Can be used when leaving the building for a longer period</p> <p>C. Nominal ventilation: Will give required air change under normal conditions.</p> <p>D. Maximum ventilation: To increase the airflow if necessary.</p> |

| Symbol | Description | Explanation |
|---|-------------|---|
|  | Service | Access the service menu by pressing the confirm button. |
|  | Alarm | Access the alarm list by pressing the confirm button. |

1. The fan can be set to OFF by activating MAN fan stop. See service menu description under functions.

Note:

It is not recommended to activate MAN fan stop (set fan to OFF) in standard households.

4 Configuration

4.1 Start up wizard

The **Start up Wizard** is a step-by-step configuration tool that starts automatically when the VTR200/B is started for the first time or when:

- a factory reset is performed
- a new print card is installed (spare part)
In this case the unit type must be entered (VTR200/B)


4.1.1 Procedure

| | |
|--|--|
| 1. Turn the knob to choose language and press confirm | Languages Language ENGLISH |
| 2. Choose unit type, this choice is only present if a new print card is installed (spare part) | Type VTR200/B |
| 3. Set date and time | Time/Date YY/MM/DD Date: 12/09/12 Time: 10:00 Weekday: Sat |
| 4. Select heater: None/Electrical/Water | Heater Heater: None/Electrical/Water |
| 5. Change default flow value. If NO is selected the Wizard is finished. | Default flow YES NO |
| If YES is selected: | |

| <p>6. Set the system curve.</p> <p>This function is implemented in the unit to compensate the flow values for different system pressures.</p> <p>Supply Fan (SF): Total value range: 1–20. For G3 type filter: 11–20, for F7 type filter: 1–10. Default curve: 4</p> <p>Extract Fan (EF): Value range: 1–10 Default curve: 4</p> <hr/> <p>Note:</p> <p>The factory installed filters are of filter quality F7 for the supply air and G3 for extract air filter. Air filters are accessories and can be obtained from the installer or wholesaler.</p> <p>The filter type is labelled on the top of the filter.</p> <hr/> | <p>System curve</p> <p>EF: 1–10 SF: 1–20</p> | | | | | | | | | | | | |
|---|---|-------------|----|----|-----|----|----|-----|----|----|-----|----|----|
| <p>7. Here it is possible to change the Nominal/High/Low air flow on the Extract and Supply air fans.</p> <p>When settings are done, press confirm.</p> | <table><tr><th>Airflow l/s</th><th>EF</th><th>SF</th></tr><tr><td>Nom</td><td>45</td><td>45</td></tr><tr><td>Max</td><td>89</td><td>89</td></tr><tr><td>Min</td><td>23</td><td>23</td></tr></table> | Airflow l/s | EF | SF | Nom | 45 | 45 | Max | 89 | 89 | Min | 23 | 23 |
| Airflow l/s | EF | SF | | | | | | | | | | | |
| Nom | 45 | 45 | | | | | | | | | | | |
| Max | 89 | 89 | | | | | | | | | | | |
| Min | 23 | 23 | | | | | | | | | | | |

4.1.2 Perform Factory reset

How to perform a factory reset if necessary:

| | |
|--|--|
| <p>1. Enter the service menu by selecting the service symbol in the display and press confirm.</p> |  |
| <p>2. Go to password and enter the password, default 1111</p> <p>Use the selection knob for each digit and confirm with the confirm button after each set digit and choose "NO" for the system not to be locked.</p> | <p>Password</p> <p>Password XXXX Locked YES/NO</p> |
| <p>3. Go to Functions and select Factory Reset</p> | <p>Functions</p> <p>→ Factory reset</p> |
| <p>4. Turn the knob so YES is shown and press confirm</p> | <p>Factory reset</p> <p>Really reset? YES/NO</p> |
| <p>5. ACCEPTED is shown in the display window</p> | <p>ACCEPTED</p> |
| <p>6. The Start up Wizard starts after approximately 10 seconds</p> | |

4.2 Temperature settings

The supply air temperature is set manually in 6 steps in the main menu display by choosing the temperature symbol. If an electrical or water re-heater is installed the temperature setpoints are: 12.0,

14.5, 17.0, 19.5 and 22.0 °C. Default value is 12.0 °C. If the re-heater is deactivated, the temperature steps are: 15.0, 16.0, 17.0, 18.0 or 19.0°C. Default value is 15.0 °C.

Each temperature step is illustrated by increasing the filling of the temperature symbol.



4.3 Manual setting of fan speed

It is possible, at any time, to manually set the fan speed in the main menu display. By choosing the fan symbol and confirming, it is possible to increase or decrease the fan speed in the 4 steps: Off, Low, Nom and High. By doing so, you override the programmed week schedule for the unit until the end of the present time period in the week program.




Note:

The fan can be set to OFF by activating MAN fan stop. See service menu description under functions.

4.4 Programming the Week schedule

Program how you want the unit to operate according to the week schedule. It's possible to set 2 periods per day.

Set the week schedule according to below procedure:

| | |
|--|--|
| 1. Go to the service menu by using the selection knob. |  |
| 2. Enter the service level by typing the password, default 1111. Use the selection knob for each digit and confirm with the confirm button after each set digit and choose "NO" for the system not to be locked. | Password Password XXXX Locked YES/NO |
| 3. Go to: Week program | Service -> Week program |
| 4. Choose Week program again. | Week program -> Week program Fan speed |
| 4. Set week day and time you want the unit to be in ON level. Two periods per day can be programmed. The rest of the time the unit will be in OFF level. | Week program Day: MON Per 1: 07:00 16:00 Per 2: 00:00 00:00 |

| | |
|---|---|
| 5. Go back to the previous dialogue frame with the Back button and go down to Fan speed. | Week program Week program -> Fan speed |
| 7. Set which fan speed the fan is supposed to be running in the ON level, choose between Low, Nom or High. Set which fan speed the fan is supposed to be running in the OFF level, choose between OFF, Low, Nom or High. <hr/> Note: If an electrical re-heater battery is installed and active and the unit is shut down from the control panel, for example by choosing OFF. When the unit is in OFF level in the week program, the fans will continue to run for 3 minutes, to prevent the heater from triggering the over heat protection sensor, before they stop. | Fan speed On level: low/nom/high Off level: off/low/nom/high |
| 8. Step back with the Back button until you reach the main menu display | |

4.5 Manual and automatic summer mode

Manual summer mode occurs if one temperature setpoint step lower than the 12 °C step is selected. The temperature symbol on the main menu is then completely empty. If the re-heater is active, it will switch off during manual summer mode. Manual summer mode aborts automatically after two minutes if the supply air temperature is ≤ 5 °C.

If a water heater battery is installed and activated, the manual summer mode is aborted if the outdoor air or supply air temperature is ≤ 5 °C.

The unit will automatically alternate between winter operation with heat recovery and summer operation without heat recovery.

5 Maintenance of the unit

Maintenance of the SAVE VTR200/B should normally be performed 3 - 4 times a year.

5.1 Warnings

Danger

- Make sure that the Mains supply to the unit is disconnected before performing any maintenance or electrical work!
- All electrical maintenance work must be carried out by an authorized installer and in accordance with local rules and regulations.

Warning

- The system should operate continuously, and only be stopped for maintenance/service
- Beware of sharp edges during maintenance. Use protective gloves.
- Make sure that filters are mounted before starting the unit

5.2 Open the front hatch

Open the hatch with the two latches and swing the hatch open.

5.3 Changing filters

The filters are to be changed every 6/9/12/15 months, default value is 9 months. When the filters have been changed the filter timer must be reset. See 5.4

The factory installed filters are of filter quality F7 for the supply air and G3 for the extract air filter. The filters need to be replaced when polluted. New sets of filters can be acquired from your installer or wholesaler.

Filter quality G3 can be installed for supply air filtering.
The filter type is labelled on the top of the filter.

Note:

If type G3 filters are used instead of F7, the system curve for Supply Fan (SF) must be changed:

For G3 type filter: 11–20, for F7 type filter: 1–10. See chapter 7.2-7.4 in Installation and Service





Fig. 2 Heat exchanger filters

5.4 Resetting the filter time

| | |
|--|--|
| 1. Go to the service menu by using the selection knob. |  |
| 2. Enter the service level by typing the password. Use the selection knob for each digit and confirm with the confirm button after each set digit and choose "NO" for the system not to be locked. | Service ->Password Locked YES/NO |
| 3. Go to: Filter period, confirm Choose: Reset: YES with the selection knob and then confirm Change, if necessary, Time to replace X month, to the time of your choice with the selection knob and then confirm Press the "back button" until you reach the main menu. | Filter period Time to replace: 6/9/12/15 month Reset NO/YES |

5.5 Checking and cleaning the heat exchanger

Danger

- Make sure that the Mains supply to the unit is disconnected before performing any maintenance or electrical work!

Even if the required maintenance is carried out, dust will build up in the exchanger block. It is therefore of vital importance for the upkeep of a high efficiency that the exchanger block is removed from the unit and cleaned periodically as illustrated below. Clean the heat exchanger at least every 3 years or when required.

1. Disconnect the rotor power supply and the rotor sensor. The cables are found beside the rotor at the back.
2. Pull out the rotor towards you. Some force may be needed.
3. Clean the rotor.

Wash in hot soapy water. Do not use detergent containing ammonia. Rinse using, for instance, a shower handle or carefully with compressed air.

Warning

Ensure the rotor motor is not exposed to moisture

4. Remount the rotor. Don't forget to reconnect the rotor power and sensor cables.




Fig. 3 Heat exchanger

5.6 Cleaning the fans

Danger

- Make sure that the Mains supply to the unit is disconnected before performing any maintenance or electrical work!

The motor bearings are life time lubricated and maintenance free.

Even if the required maintenance, such as changing of filters is carried out, dust and grease may slowly build up inside the fans. This will reduce the efficiency.

The fans may be cleaned as illustrated in below procedure.

1. Disconnect the fan power cables. The cables are found beside the fan at the back.
2. Pull out the fans towards you. Some force may be needed.
3. Clean the fans with a cloth or a soft brush. Do not use water. White spirit can be used to remove obstinate deposits.

Allow the fans to dry properly before remounting.

4. Remount the fans. Don't forget to reconnect the fan power cables.




Fig. 4 Extract and supply air fans

6 Duct system maintenance

6.1 Cleaning extract louvres and supply air diffusers

The system supplies fresh air to your home and extracts the used indoor air via the duct system and diffusers/louvres. Diffusers and louvres are mounted in ceilings/walls in bedrooms, living room, wet rooms, WC etc. Remove diffusers and louvres and wash in hot soapy water as required (diffusers/louvres must not be exchanged). Cleaning of diffusers/louvres can be done as necessary.




Fig. 5 Diffusers and louvres

6.2 Checking the outdoor air intake

Leaves and pollution could plug up the air intake grille (figure 9) and reduce the capacity. Check the air intake grille, and clean as necessary. It is recommended to do this at least twice a year.




Fig. 6 Intake grill

6.3 Checking the roof cowl (if fitted)

The roof cowl (if fitted) connected to the exhaust air duct needs to be checked at least twice a year and cleaned if necessary.

6.4 Checking and cleaning the duct system

Dust and grease deposits may build up in the duct system, even if required maintenance such as changing of filters is being carried out. This will reduce the efficiency of the installation.

The duct runs should therefore be cleaned/changed when necessary. Steel ducts can be cleaned by pulling a brush soaked in hot soapy water, through the duct via diffuser/louvre openings or special inspection hatches in the duct system (if fitted).

It is recommended to do this every 5 years and is normally carried out by authorized companies specialized in this area.




Fig. 7 Cleaning duct system

7 Trouble shooting

A warning triangle with text in the display indicates an alarm. Turn menu selector to the warning triangle and press confirm twice to view the alarm.

7.1 Alarm list

| Alarm | Explanation | Do the following |
|-----------|---|---|
| Fan | Indicates error on either supply or extract air fan. | <p>The alarm is displayed in the control panel.</p> <p>Contact your installation company or place of purchase.</p> |
| EMT/Frost | Indicates triggered overheat protection (in case of installed electric re-heater battery) or frost protection (in case of installed water heating battery). | <p>A triggered frost protection alarm results in the following:</p> <ul style="list-style-type: none"> • Both fans stop. • Outdoor and exhaust air dampers close. • Water valve opens completely (10 V signal goes out to the actuator). <p>The unit will restart once the water temperature reaches +5K above the set frost protection temperature.</p> <p>A triggered over heat protection gives an alarm in the control panel.</p> <p>Reset by pushing the red button on the front of the heater.</p> <p>If the problem continues contact your installation company or place of purchase.</p> |
| Rotor | Indicates a rotor malfunction. | <p>The alarm is displayed in the control panel.</p> <p>The rotating heat exchanger has stopped. Check the rotor belt.</p> <p>If the heat exchanger is still rotating, the rotor sensor may be faulty.</p> <p>Contact your installation company or place of purchase.</p> |
| Pb Fail | Error in connection with relay card for the electrical re-heater (if installed and activated). | <p>The alarm is displayed in the control panel.</p> <p>The heater will not be activated.</p> <p>Contact your installation company or place of purchase.</p> |
| Temp | Malfunction in one or more of the temperature sensors. | <p>The alarm is displayed in the control panel.</p> <p>Contact your installation company or place of purchase.</p> |
| Filter | Time for filter change. | <p>The alarm is displayed in the control panel.</p> <p>Change filter according to the instructions in chapter 5.3.</p> |

Systemair AB reserves the right to make changes and improvements to the contents of this manual without prior notice.



Systemair AB
Industrivägen 3
SE-739 30 Skinnkatteberg, Sweden

Phone +46 222 440 00

Fax +46 222 440 99

www.systemair.com